



Presets


Clear (Flat)




TS




DtS




ClearS (FlatS)




TsS




LiveS




L-3




L-6




RockS




R-3




R-6




ExtS




WarmS



Press



LoudS



- To enable Speakon output, just select a preset with S suffix. (ClearS, LiveS, etc.)
- To upload new presets on the KF12 it's needed the K-USB interface.
- To have news about new presets just send an e-mail with "KF12" as text at info@k-array.com